

Rear Brake Spring Pedal Return Kit Installation Instructions

Before removing any parts, load the brake pedal to the point of first activation.

Once loaded, draw a horizontal and vertical line from the pedal to the frame. This will give you a good reference point to avoid chasing the pedal height while adjusting it.

Remove clevis and jam nut.

Insert the Fasst Company spring over the rubber dust boot and thread the Spring Bucket onto the threaded master cylinder shaft.

Install clevis.

The Spring Bucket can take the place of the stock jam nut if a Fasst Company Brake Clevis is used. If a heavy pedal feel is desired tighten the Spring Bucket up against the nut that retains the dust boot. If a lighter feel is desired the Spring Bucket can be tighten against the clevis. If you tighten the Spring Bucket against the clevis be sure there is no play in the spring between the Spring Bucket and the master cylinder.