

Part #10-220 Skid Plate Instructions

USE SOME FORM OF THREAD LOCKING COMPOUND ON THE FASTENERS. #242 BLUE LOC-TITE IS RECOMMENDED.

This Skid Plate uses three different brackets.

NOTE-The bracket with the shortest hook is the right rear bracket.

The two front brackets have a relief machined into them to clear a weld bead on the frame rails

The easiest way to install the Skid Plate is to slip all four brackets over the frame rails in their approximate positions. Hold the Skid Plate up to the frame and install the screws through the Skid Plate up into the brackets and leave them loose for now. Install the 6mm bolts and also leave them loose for the time being. Adjust the Skid Plate into its proper position and tighten all of the fasteners securely.

TIP-To ensure the Skid Plate mating tightly against the frame rails, we recommend using an impact screwdriver and giving the screws two to three light hits.